

SR60 Busbar System

Partition components

Overview

- ① Edges
- ② Bases
- ③ Edges
- ④ Supports for the blanking covers
- ⑤ End cover
- ⑥ Blanking covers
- ⑦ Busbar support, 3-phase
- ⑧ Busbar support for N/PE

