



CP50M0

PROFIBUS DP

X1



X2



PROFIBUS DP

Pin assignment

RS 232 (download)

TxD = 2

RxD = 7

Ground = 1

RS 485 (PROFIBUS)

+Tx/Rx-Sig. = 3

-Tx/Rx-Sig. = 8

Ground = 5