


Dimensional drawings


5TT4 1 remote control switches

5TT4 101- 5TT4 102- 5TT4 103- 5TT4 104-
5TT4 105-
5TT4 115-..




5TT4 12 remote control switches with central ON/OFF switching

5TT4 122-0 5TT4 123-0
5TT4 125-0



5TT4 132-0 series remote control switches and 5TT4 142 shutter/blind remote control switches


5TT4 132-
5TT4 142-



1) ZE = Central ON; ZA = Central OFF


Remote control switches with central and group ON/OFF switching

5TT4 151-, 5TT4 152-




Auxiliary switches

5TT4 90.



Compensators

5TT4 920



1) GE = Group ON; GA = Group OFF